



## NKCR2.E68961 Auxiliary Devices - Component

Page Bottom



## Auxiliary Devices - Component

See General Information for Auxiliary Devices - Component

**IDEC CORP**

7-31 NISHIMIYAHARA 1-CHOME  
YODOGAWA-KU, OSAKA 532-8550 JAPAN

E68961

**Combination display lights**, Model SLC30N followed by 01 through 10, followed by 01 through 20, followed by -DD, -DF, -DHM, -DS, -DW, -TD, -TE or -TS, followed by 1, 2, 3, 6 or 8, may be followed by -NKCR2; Model SLC40N followed by 01 through 07, followed by 01 through 15, followed by -DD, -DE, -DEM, -DF, -DHT, -DW, -TD or -TE, followed by 1, 2, 3, 6 or 8, may be followed by -NKCR2.

Model LD6A, may be followed by -1, -2, -3, -4 or -5, followed by D, W, G, P or K, may be followed by Z, may be followed by any letter(s) and/or number(s).

**Enabling switches**, Model HE1B-M1 may be followed by additional numbers of letters.

Model HE2B -M2 or -M6 may be followed by additional numbers or letters.

Model HE3B-M2, HE5B-M2 may be followed by additional numbers or letters.

**LED illuminated display lights**, Model SLC followed by 30 or 40, followed by -0101, -0102, -0103 or -0202, may be followed by additional suffixes; Model SLD followed by 24, may be followed by additional suffixes.

**LED illuminated miniature pilot lights**, AP Series, Models AP1M, AP2M, AP6M, AP8M.

**Magnetically operated switches**, Cat. No. RV3S followed by B or G, followed by DC3V through DC24V incl.

**Magnetically operated switch, for use in electronic data processing equipment or office appliance and business equipment (nonindustrial)**, Type RV3S may be followed by B, G, 3B or 3G, followed by 05S thru 24S incl: Relay socket, Type RV9Z-S01.

**Transformers**, Models AP2, APG.

Series RV3T followed by -1G, -2G or -3G, may be followed by 03, 04, 05, 06, 09, 10, 12, 15, 18, 21 or 24.

**Push buttons**, Model XW Series.

Models XN Series, XNxx-xxxxxxx-BC\* Series.

**Push button switches**, Model HA may be followed by 1, may be followed by E, followed by -, may be followed by V, may be followed by 2, followed by S, may be followed by 1 or 2, may be followed by V, may be followed by R, N, Y, B, G, W or S, may be followed by additional letters and/or numbers.

Types XW1E, XA1E followed by -BV, -LV, or -TV, followed by 3 or 4, followed by 0 through 3, followed by 1 through 4, may be followed by Q4, Q3, Q2, Q1, may be followed by V, followed by R, N, Y, B, G, W or S.

Model XW1E-XXXXXXX-BC Series.

Model XA1E Unibody Type.

**Grip switch enclosures**, Model HE9Z.

**Auxiliary devices**, Model HS5E Series.